

The Caffenu® cleaning pod was specifically designed to clean the brewing chamber and spout of your Nespresso® Vertuo®\* coffee machine.

**RECOMMENDED USAGE:** Use one cleaning capsule after every 30 cups, or at least once a month. Office use: Clean weekly. NOT A DESCALER! Please also remember to descale your machine with the Caffenu® Eco Descaler for Vertuo®\*. \*Estimated Duration: 10 - 15mins

caffenu®

Cleaner Machine  
Better Coffee

### General Instructions BEFORE CLEANING for ALL Vertuo®\* Machines

1. Rinse the water tank; then fill with fresh water. Put the water tank in place.
2. Ensure any coffee pods are ejected and the pod basket is empty.
3. Place a container of at least 34 fl oz/1 L under coffee spout.

### CLEANING GUIDELINES FOR NESPRESSO® VERTUO®\*

(OPEN & TURN FOR DESCALING INSTRUCTIONS)



### Cleaning Instructions for ALL Vertuo®\* Machines

1. Please ensure that you have followed the general instructions BEFORE CLEANING as above.
2. Turn the machine on to heat up until the light is steady.
3. Place one Caffenu® cleaning pod in the machine (like a coffee pod).
4. Close the machine head and turn the lever into "LOCKED" position (Vertuo®\* Plus locks automatically).
5. Push the button 3 times within 2 seconds to start the cleaning cycle. The light will blink during the cycle. It will take +- 1½ minutes before a flow begins. The cleaning cycle will run for 5-7 minutes. Light will become steady once complete.



If machine light flashes red, or cycle does not begin: Open machine and ensure capsule is inserted correctly and level; repeat step 4 & 5.

6. Unlock machine and remove pod. **CAUTION!** Pod is hot!
7. Remove pod basket and drip tray from machine and dispose of cleaning pod.
8. Rinse pod basket and drip tray and place empty container back under spout.
9. Ensure water tank is full.
10. Repeat steps 2, 4 & 5 to perform rinsing procedure (Do not insert pod!).
11. Gently wipe down machine and inside machine head (capsule holder and brew needle).
12. Machine is now ready for use.

### TOP TIP

Soak pod basket and drip tray in container with solution for 2 minutes, then rinse with water.

**CAUTION:** Do not use any corrosive cleaning agents. Not dishwasher-safe. Never submerge the machine in water or any other liquid. Wipe the coffee spout and rest of the machine off regularly with a clean damp cloth.

**NOTE:** Water could build up inside the machine's head and pod holder during cleaning. Dry the accessible areas with a clean dry cloth if this happens.

\*Caffenu® is not a product of Nespresso® Vertuo® nor is related in any way. Nespresso® Vertuo® is a registered trademark of Société Des Produits Nestlé S.A.